


Mounting Instructions

Important! The E.A.W. Mount will give you a life time of reliable service if you follow the instructions. The unique design assures a totally stress free mounting of your scope and the various adjustments allow you to remove all play.



- Clean and degrease top of receiver, bottom of bases and inside of rings.
- Remove rear ring from base. Install mount bases, being very careful not to get Loc-Tite into adjustments.
- Loosen levelling screws under front ring (A) and tension adjustment in front base (C).
- Swing front ring in place and reinstall rear ring and opposing windage screws.
- 5. Remove upper parts of the split rings.



- 6. Place scope into lower rings and check eye relief and alignment with Collimator or by bore-sighting. If the elevation is too far off, do not shim bases. The rear ring is available in different heights in .020" increments. Exchange the ring you have with one of the proper height.
- 7. Snap upper portion of scope rings in place using the following procedure to avoid scratching of the scope tube: Slip the piece of plastic supplied under both sides of the ring as shown in picture (E), snap ring in place and remove plastic.